

Boost Control Valve



Sensor Pin	Output	ECU Pin Type
Pin 1	Power	12v
Pin 2	Ground	Ground

Polarity does not matter when wiring. A diode should be fitted between the 2 wires with the grey line towards the 12v wire.

