

6 Cylinder Coil Pack



Sensor Pin	Output	ECU Pin Type
Pin 1	12v Ignition	12v Ignition
Pin 2	Coil A	Coil 1
Pin 3	Coil B	Coil 2
Pin 4	Coil C	Coil 3

