


Vauxhall Coil Pack



Sensor Pin	Output	ECU Pin Type
Pin 1	Coil A	Coil 1
Pin 2	Coil B	Coil 2
Pin 3	12v Ignition	12v Ignition
Pin 4	Not Connected	Not Connected